

Telephone:
Fax:
VAT Registration No.:

Name:		Manufacturer:	BMW
Address:		Model:	e38
		Year:	1996
		Registration:	
Tel - Private:		Mileage:	
Tel - Business:		Job number:	

Oil service LED

Switch ignition ON.

Connect LED test lamp between terminal 7 of the engine diagnostic connector and earth **Fig. 84765**. Diagnostic connector located adjacent to left or right-hand turret or on bulkhead.

After 3 seconds 5 green LED's will illuminate.

Switch ignition OFF.

